



60 Centimes le Nu
MURAGE
LA BRODERIE
TRAVAUX DE DAMES
PARIS (XIV)
238



111 13 002
26cmディナー皿
D-26 H-3.2 ¥2,300

111 13 004
23cmミート皿
D-23.2 H-3 ¥1,600

111 13 006
19.5cmケーキ皿
D-19.8 H-2.9 ¥1,100

111 13 008
15cmパン皿
D-15 H-2.5 ¥900



111 13 097
19cmラザニア
L-19.6 S-12 H-3.4 ¥1,800



111 13 072
グラタン
L-16 S-14.3 H-5 ¥2,300



161 13 012
22cmパスタボウル
D-22.4 H-3.7 ¥1,600



113 13 044
28.5cmオーバルプラター
L-29 S-22.6 H-3.7 ¥3,400



113 13 071
27cmオーバルペーカ
L-27 S-17.4 H-5.4 ¥3,400



111 13 043
31.5cmプラター
L-31.8 S-22 H-3.7 ¥4,900



111 13 045
26cmプラター
L-26.2 S-18.2 H-2.7 ¥3,100



111 13 046
24cmプラター
L-24 S-17 H-2.7 ¥2,300



111 13 021
23cmボウル
D-23.2 H-8.3 ¥2,800



111 13 023
20cmボウル
D-20 H-7 ¥2,400



111 13 024
17cmボウル
D-17 H-6.3 ¥1,500



111 13 025
13.5cmボウル
D-13.7 H-5.5 ¥950



111 13 027
10cmボウル
D-10.2 H-4.1 ¥800



113 13 063
クリーマー
L-10.5 S-8.1 H-7.9 C-200cc ¥1,500



113 13 051
ダイナーマグカップ
L-12.2 S-8.8 H-9.3 C-345cc ¥1,400



113 13 052
ダイナーカップ
L-11.4 S-8 H-8.6 C-240cc ¥1,300



113 13 053
ダイナーコーヒーカップ
L-10.1 S-7.4 H-7.7 C-200cc ¥1,100



113 13 050
高台割りマグカップ
L-12.2 S-8.8 H-10.4 C-330cc ¥1,400



111 13 052
コーヒーカップ
L-10.5 S-7.8 H-7.3 C-180cc ¥800



111 13 053
ティーカップ
L-12.5 S-9.9 H-5.8 C-240cc ¥900



113 13 056
ダイナースープカップ
L-13.2 S-10.5 H-6.3 C-340cc ¥1,600



111 13 058
片手スープカップ
L-14.8 S-12 H-6.4 C-340cc ¥1,400

161 13 055
モア兼用ソーサー
D-15.3 H-2 ¥700

111 13 056
コーヒーソーサー
D-14.3 H-2.5 ¥700

161 13 055
モア兼用ソーサー
D-15.3 H-2 ¥700

111 13 056
コーヒーソーサー
D-14.3 H-2.5 ¥700

111 13 055
兼用ソーサー
D-15.3 H-2.5 ¥750

111 13 055
兼用ソーサー
D-15.3 H-2.5 ¥750

111 13 055
兼用ソーサー
D-15.3 H-2.5 ¥750



COUNTRY SIDE
FALLS BLUE | フォールズブルー



111 88 002
26cmディナー皿
D-26 H-3.2 ¥2,400

111 88 004
23cmミート皿
D-23.2 H-3 ¥1,700

111 88 006
19.5cmケーキ皿
D-19.8 H-2.9 ¥1,300

111 88 008
15cmパン皿
D-15 H-2.5 ¥950



111 88 097
19cmラザニア
L-19.7 S-12.2 H-3.5 ¥1,900



111 88 072
グラタン
L-16 S-14.4 H-5.1 ¥2,400



161 88 012
22cmパスタボウル
D-22.4 H-3.7 ¥1,700



113 88 044
28.5cmオーバルプラター
L-29.1 S-22.5 H-4 ¥3,600



113 88 071
27cmオーバルペーカー
L-27 S-17.2 H-5.5 ¥3,600



111 88 043
31.5cmプラター
L-31.8 S-22 H-3.7 ¥5,100



111 88 045
26cmプラター
L-26.2 S-18.2 H-2.7 ¥3,300



111 88 046
24cmプラター
L-24 S-17 H-2.7 ¥2,400



111 88 021
23cmボウル
D-23.2 H-8.3 ¥2,900



111 88 023
20cmボウル
D-20 H-7 ¥2,700



111 88 024
17cmボウル
D-17 H-6.3 ¥1,600



111 88 025
13.5cmボウル
D-13.7 H-5.5 ¥1,000



111 88 027
10cmボウル
D-10.2 H-4.1 ¥850



113 88 063
クリーマー
L-10.7 S-8.1 H-8 C-200cc ¥1,700



113 88 051
ダイナーマグカップ
L-12.2 S-8.8 H-9.3 C-345cc ¥1,500



113 88 052
ダイナーカップ
L-11.4 S-8 H-8.6 C-240cc ¥1,400

161 88 055
モア兼用ソーサー
D-15.3 H-2 ¥750



113 88 053
ダイナーコーヒーカップ
L-10.1 S-7.5 H-7.8 C-200cc ¥1,300

111 88 056
コーヒーソーサー
D-14.3 H-2.5 ¥750



113 88 050
高台割りマグカップ
L-12.2 S-8.8 H-10.4 C-330cc ¥1,500

161 88 055
モア兼用ソーサー
D-15.3 H-2 ¥750



111 88 052
コーヒーカップ
L-10.5 S-7.8 H-7.3 C-180cc ¥1,000

111 88 056
コーヒーソーサー
D-14.3 H-2.5 ¥750



111 88 053
ティーカップ
L-12.5 S-9.9 H-5.8 C-240cc ¥1,100

111 88 055
兼用ソーサー
D-15.3 H-2.5 ¥800



113 88 056
ダイナースープカップ
L-13.2 S-10.5 H-6.3 C-340cc ¥1,700

111 88 055
兼用ソーサー
D-15.3 H-2.5 ¥800



111 88 058
片手スープカップ
L-15 S-12.1 H-6.4 C-340cc ¥1,500

111 88 055
兼用ソーサー
D-15.3 H-2.5 ¥800

COUNTRY SIDE
STORM GRAY | ストームグレー



111 73 002
26cmディナー皿
D-26 H-3.2 ¥2,700

111 73 004
23cmミート皿
D-23.2 H-3 ¥1,900

111 73 006
19.5cmケーキ皿
D-19.8 H-2.9 ¥1,400

111 73 008
15cmパン皿
D-15 H-2.5 ¥1,100



111 73 097
19cmラザニア
L-19.7 S-12.2 H-3.5 ¥2,100



111 73 072
グラタン
L-16 S-14.4 H-5.1 ¥2,600



161 73 012
22cmパスタボウル
D-22.4 H-3.7 ¥1,900



113 73 046
28.5cmオーバルプラター
L-29.1 S-22.5 H-4 ¥4,000



113 73 071
27cmオーバルベーカー
L-27 S-17.2 H-5.5 ¥4,000



111 73 046
31.5cmプラター
L-31.8 S-22 H-3.7 ¥5,500



111 73 047
26cmプラター
L-26.2 S-18.2 H-2.7 ¥3,700



111 73 048
24cmプラター
L-24 S-17 H-2.7 ¥2,700



111 73 021
23cmボウル
D-23.2 H-8.3 ¥3,300



111 73 023
20cmボウル
D-20 H-7 ¥3,000



111 73 024
17cmボウル
D-17 H-6.3 ¥1,800



111 73 025
13.5cmボウル
D-13.7 H-5.5 ¥1,200



111 73 027
10cmボウル
D-10.2 H-4.1 ¥950



113 73 051
ダイナーマグカップ
L-12.2 S-8.8 H-9.3
C-345cc ¥1,600



113 73 052
ダイナーカップ
L-11.4 S-8 H-8.6
C-240cc ¥1,500



113 73 050
高台削りマグカップ
L-12.2 S-8.8 H-10.4
C-330cc ¥1,600



111 73 052
コーヒーカップ
L-10.5 S-7.8 H-7.3
C-180cc ¥1,100



111 73 053
ティーカップ
L-12.5 S-9.9 H-5.8
C-240cc ¥1,100



113 73 056
ダイナースープカップ
L-13.2 S-10.5 H-6.3
C-340cc ¥1,800



111 73 058
片手スープカップ
L-15 S-12.1 H-6.4
C-340cc ¥1,600

161 73 055
モア兼用ソーサー
D-15.3 H-2 ¥800

161 73 055
モア兼用ソーサー
D-15.3 H-2 ¥800

111 73 056
コーヒーソーサー
D-14.3 H-2.5 ¥800

111 73 055
兼用ソーサー
D-15.3 H-2.5 ¥850

111 73 055
兼用ソーサー
D-15.3 H-2.5 ¥850

111 73 055
兼用ソーサー
D-15.3 H-2.5 ¥850



111 60 002
26cmディナー皿
D-26 H-3.2 ¥2,400

111 60 004
23cmミート皿
D-23.2 H-3 ¥1,700

111 60 006
19.5cmケーキ皿
D-19.8 H-2.9 ¥1,300

111 60 008
15cmパン皿
D-15 H-2.5 ¥950



111 60 097
19cmラザニア
L-19.7 S-12.2 H-3.5 ¥1,900



111 60 072
グラタン
L-16 S-14.4 H-5.1 ¥2,400



161 60 012
22cmパスタボウル
D-22.4 H-3.7 ¥1,700



113 60 044
28.5cmオーバルプラター
L-29.1 S-22.5 H-4 ¥3,600



113 60 071
27cmオーバルペーカー
L-27 S-17.2 H-5.5 ¥3,600



111 60 043
31.5cmプラター
L-31.8 S-22 H-3.7 ¥5,100



111 60 045
26cmプラター
L-26.2 S-18.2 H-2.7 ¥3,300



111 60 046
24cmプラター
L-24 S-17 H-2.7 ¥2,400



111 60 021
23cmボウル
D-23.2 H-8.3 ¥2,900



111 60 023
20cmボウル
D-20 H-7 ¥2,700



111 60 024
17cmボウル
D-17 H-6.3 ¥1,600



111 60 025
13.5cmボウル
D-13.7 H-5.5 ¥1,000



111 60 027
10cmボウル
D-10.2 H-4.1 ¥850



113 60 063
クリーマー
L-10.7 S-8.1 H-8 C-200cc ¥1,700



113 60 051
ダイナーマグカップ
L-12.2 S-8.8 H-9.3 C-345cc ¥1,500



113 60 052
ダイナーカップ
L-11.4 S-8 H-8.6 C-240cc ¥1,400



113 60 053
ダイナーコーヒーカップ
L-10.1 S-7.5 H-7.8 C-200cc ¥1,300



113 60 050
高台割りマグカップ
L-12.2 S-8.8 H-10.4 C-330cc ¥1,500



111 60 052
コーヒーカップ
L-10.5 S-7.8 H-7.3 C-180cc ¥1,000



111 60 053
ティーカップ
L-12.5 S-9.9 H-5.8 C-240cc ¥1,100



113 60 056
ダイナースープカップ
L-13.2 S-10.5 H-6.3 C-340cc ¥1,700



111 60 058
片手スープカップ
L-15 S-12.1 H-6.4 C-340cc ¥1,500

161 60 055
モア兼用ソーサー
D-15.3 H-2 ¥750

111 60 056
コーヒーソーサー
D-14.3 H-2.5 ¥750

161 60 055
モア兼用ソーサー
D-15.3 H-2 ¥750

111 60 056
コーヒーソーサー
D-14.3 H-2.5 ¥750

111 60 055
兼用ソーサー
D-15.3 H-2.5 ¥800

111 60 055
兼用ソーサー
D-15.3 H-2.5 ¥800

111 60 055
兼用ソーサー
D-15.3 H-2.5 ¥800

COUNTRY SIDE
JADE | ジェイド



111 70 002
26cmディナー皿
D-26 H-3.2 ¥2,400

111 70 004
23cmミート皿
D-23.2 H-3 ¥1,700

111 70 006
19.5cmケーキ皿
D-19.8 H-2.9 ¥1,300

111 70 008
15cmパン皿
D-15 H-2.5 ¥950



111 70 097
19cmラザニア
L-19.7 S-12.2 H-3.5 ¥1,900



111 70 072
グラタン
L-16 S-14.4 H-5.1 ¥2,400



161 70 012
22cmパスタボウル
D-22.4 H-3.7 ¥1,700



113 70 044
28.5cmオーバルプラター
L-29.1 S-22.5 H-4 ¥3,600



113 70 071
27cmオーバルペーカー
L-27 S-17.2 H-5.5 ¥3,600



111 70 043
31.5cmプラター
L-31.8 S-22 H-3.7 ¥5,100



111 70 045
26cmプラター
L-26.2 S-18.2 H-2.7 ¥3,300



111 70 046
24cmプラター
L-24 S-17 H-2.7 ¥2,400



111 70 021
23cmボウル
D-23.2 H-8.3 ¥2,900



111 70 023
20cmボウル
D-20 H-7 ¥2,700



111 70 024
17cmボウル
D-17 H-6.3 ¥1,600



111 70 025
13.5cmボウル
D-13.7 H-5.5 ¥1,000



111 70 027
10cmボウル
D-10.2 H-4.1 ¥850



113 70 063
クリーマー
L-10.7 S-8.1 H-8 C-200cc ¥1,700



113 70 051
ダイナーマグカップ
L-12.2 S-8.8 H-9.3 C-345cc ¥1,500



113 70 052
ダイナーカップ
L-11.4 S-8 H-8.6 C-240cc ¥1,400



113 70 053
ダイナーコーヒーカップ
L-10.1 S-7.5 H-7.8 C-200cc ¥1,300



113 70 050
高台割リマグカップ
L-12.2 S-8.8 H-10.4 C-330cc ¥1,500



111 70 052
コーヒーカップ
L-10.5 S-7.8 H-7.3 C-180cc ¥1,000



111 70 053
ティーカップ
L-12.5 S-9.9 H-5.8 C-240cc ¥1,100



113 70 056
ダイナースープカップ
L-13.2 S-10.5 H-6.3 C-340cc ¥1,700



111 70 058
片手スープカップ
L-15 S-12.1 H-6.4 C-340cc ¥1,500

161 70 055
モア兼用ソーサー
D-15.3 H-2 ¥750

111 70 056
コーヒーソーサー
D-14.3 H-2.5 ¥750

161 70 055
モア兼用ソーサー
D-15.3 H-2 ¥750

111 70 056
コーヒーソーサー
D-14.3 H-2.5 ¥750

111 70 055
兼用ソーサー
D-15.3 H-2.5 ¥800

111 70 055
兼用ソーサー
D-15.3 H-2.5 ¥800

111 70 055
兼用ソーサー
D-15.3 H-2.5 ¥800



111 86 002
26cmディナー皿
D-26 H-3.2 ¥2,400

111 86 004
23cmミート皿
D-23.2 H-3 ¥1,700

111 86 006
19.5cmケーキ皿
D-19.8 H-2.9 ¥1,300

111 86 008
15cmパン皿
D-15 H-2.5 ¥950



111 86 097
19cmラザニア
L-19.7 S-12.2 H-3.5 ¥1,900



111 86 072
グラタン
L-16 S-14.4 H-5.1 ¥2,400



161 86 012
22cmパスタボウル
D-22.4 H-3.7 ¥1,700



113 86 044
28.5cmオーバルプラター
L-29.1 S-22.5 H-4 ¥3,600



113 86 071
27cmオーバルペーカー
L-27 S-17.2 H-5.5 ¥3,600



111 86 043
31.5cmプラター
L-31.8 S-22 H-3.7 ¥5,100



111 86 045
26cmプラター
L-26.2 S-18.2 H-2.7 ¥3,300



111 86 046
24cmプラター
L-24 S-17 H-2.7 ¥2,400



111 86 021
23cmボウル
D-23.2 H-8.3 ¥2,900



111 86 023
20cmボウル
D-20 H-7 ¥2,700



111 86 024
17cmボウル
D-17 H-6.3 ¥1,600



111 86 025
13.5cmボウル
D-13.7 H-5.5 ¥1,000



111 86 027
10cmボウル
D-10.2 H-4.1 ¥850



113 86 063
クリーマー
L-10.7 S-8.1 H-8 C-200cc ¥1,700



113 86 051
ダイナーマグカップ
L-12.2 S-8.8 H-9.3 C-345cc ¥1,500



113 86 052
ダイナーカップ
L-11.4 S-8 H-8.6 C-240cc ¥1,400



113 86 053
ダイナーコーヒーカップ
L-10.1 S-7.5 H-7.8 C-200cc ¥1,300



113 86 050
高台割リマグカップ
L-12.2 S-8.8 H-10.4 C-330cc ¥1,500



111 86 052
コーヒーカップ
L-10.5 S-7.8 H-7.3 C-180cc ¥1,000



111 86 053
ティーカップ
L-12.5 S-9.9 H-5.8 C-240cc ¥1,100



113 86 056
ダイナースープカップ
L-13.2 S-10.5 H-6.3 C-340cc ¥1,700



111 86 058
片手スープカップ
L-15 S-12.1 H-6.4 C-340cc ¥1,500

161 86 055
モア兼用ソーサー
D-15.3 H-2 ¥750

111 86 056
コーヒーソーサー
D-14.3 H-2.5 ¥750

161 86 055
モア兼用ソーサー
D-15.3 H-2 ¥750

111 86 056
コーヒーソーサー
D-14.3 H-2.5 ¥750

111 86 055
兼用ソーサー
D-15.3 H-2.5 ¥800

111 86 055
兼用ソーサー
D-15.3 H-2.5 ¥800

111 86 055
兼用ソーサー
D-15.3 H-2.5 ¥800

COUNTRY SIDE
CHARCOAL BROWN | チャコールブラウン



111 61 002
26cmディナー皿
D-26 H-3.2 ¥2,400

111 61 004
23cmミート皿
D-23.2 H-3 ¥1,700

111 61 006
19.5cmケーキ皿
D-19.8 H-2.9 ¥1,300

111 61 008
15cmパン皿
D-15 H-2.5 ¥950



111 61 097
19cmラザニア
L-19.7 S-12.2 H-3.5 ¥1,900



111 61 072
グラタン
L-16 S-14.4 H-5.1 ¥2,400



161 61 012
22cmパスタボウル
D-22.4 H-3.7 ¥1,700



113 61 044
28.5cmオーバルプラター
L-29.1 S-22.5 H-4 ¥3,600



113 61 071
27cmオーバルペーカ
L-27 S-17.2 H-5.5 ¥3,600



111 61 043
31.5cmプラター
L-31.8 S-22 H-3.7 ¥5,100



111 61 045
26cmプラター
L-26.2 S-18.2 H-2.7 ¥3,300



111 61 046
24cmプラター
L-24 S-17 H-2.7 ¥2,400



111 61 021
23cmボウル
D-23.2 H-8.3 ¥2,900



111 61 023
20cmボウル
D-20 H-7 ¥2,700



111 61 024
17cmボウル
D-17 H-6.3 ¥1,600



111 61 025
13.5cmボウル
D-13.7 H-5.5 ¥1,000



111 61 027
10cmボウル
D-10.2 H-4.1 ¥850



113 61 063
クリーマー
L-10.7 S-8.1 H-8 C-200cc ¥1,700



113 61 051
ダイナーマグカップ
L-12.2 S-8.8 H-9.3 C-345cc ¥1,500



113 61 052
ダイナーカップ
L-11.4 S-8 H-8.6 C-240cc ¥1,400



113 61 053
ダイナーコーヒーカップ
L-10.1 S-7.5 H-7.8 C-200cc ¥1,300



113 61 050
高台割りマグカップ
L-12.2 S-8.8 H-10.4 C-330cc ¥1,500



111 61 052
コーヒーカップ
L-10.5 S-7.8 H-7.3 C-180cc ¥1,000



111 61 053
ティーカップ
L-12.5 S-9.9 H-5.8 C-240cc ¥1,100



113 61 056
ダイナースープカップ
L-13.2 S-10.5 H-6.3 C-340cc ¥1,700



111 61 058
片手スープカップ
L-15 S-12.1 H-6.4 C-340cc ¥1,500

161 61 055
モア兼用ソーサー
D-15.3 H-2 ¥750

111 61 056
コーヒーソーサー
D-14.3 H-2.5 ¥750

161 61 055
モア兼用ソーサー
D-15.3 H-2 ¥750

111 61 056
コーヒーソーサー
D-14.3 H-2.5 ¥750

111 61 055
兼用ソーサー
D-15.3 H-2.5 ¥800

111 61 055
兼用ソーサー
D-15.3 H-2.5 ¥800

111 61 055
兼用ソーサー
D-15.3 H-2.5 ¥800