



151 20 001
30cm大皿
D-30 H-3.3 **¥3,800**



151 20 002
27cmディナー皿
D-27 H-2.7 **¥2,000**



151 20 003
24cmミート皿
D-24 H-2.4 **¥1,300**



151 20 005
20cmケーキ皿
D-20 H-2.4 **¥950**



151 20 008
16cmパン皿
D-16.2 H-1.9 **¥700**



151 20 010
11cm小皿
D-11 H-2 **¥600**



151 20 025
14cmボウル
D-14 H-5 **¥950**



151 20 026
11.5cmボウル
D-11.7 H-4.5 **¥850**



151 20 027
9cmボウル
D-9.1 H-4 **¥700**



151 20 012
23cmスープボウル
D-23 H-4 **¥1,400**



151 20 013
19cmクープスープボウル
D-19 H-3.3 **¥1,100**



151 20 014
16cmフルーツボウル
D-16 H-3 **¥850**



151 20 051
アメリカンカップ
L-11 S-8.7 H-7.4 C-260cc **¥950**
151 20 055
兼用ソーサー
D-15 H-2.2 **¥650**



151 20 052
コーヒーカップ
L-10.5 S-8 H-6.7 C-180cc **¥850**
151 20 056
コーヒーソーサー
D-13.6 H-2 **¥600**



151 20 053
ティーカップ
L-11.3 S-9 H-5.9 C-200cc **¥900**
151 20 055
兼用ソーサー
D-15 H-2.2 **¥650**