



134 27 002
27cmディナー皿
D-27.0 H-2.7
¥2,200



134 27 003
25.5cmディナー皿
D-25.6 H-2.6
¥2,000



134 27 004
23cmミート皿
D-23.4 H-2.2
¥1,300



134 27 005
21cmミート皿
D-21.3 H-2.2
¥1,100



134 27 006
20cmケーキ皿
D-19.8 H-2
¥1,000



134 27 007
17.5cmケーキ皿
D-17.7 H-1.8
¥850



134 27 008
16cmパン皿
D-16 H-1.7
¥700



134 27 042
32.5cmプラター
L-32.6 S-22.8 H-3.9 ¥4,400



134 27 044
29cmプラター
L-29 S-20.1 H-3.6 ¥3,300



134 27 045
26.5cmプラター
L-26.5 S-18.2 H-3.4 ¥2,900



134 27 022
22cmスープ/パスタ
D-22.3 H-5.2 ￥1,500



134 27 023
19cmスープボウル
D-19.2 H-4.4 ￥1,300



134 27 024
15.5cmフルーツボウル
D-15.5 H-5.1 ￥1,000



107 27 010
25.5cmパスタボウル
D-25.5 H-5.1 ￥2,200



107 27 011
24cmパスタボウル
D-24.1 H-4.9 ￥2,000



107 27 012
22.5cmパスタボウル
D-22.5 H-4.6 ￥1,600



134 27 016
12.5cmディップ
D-12.6 H-2.7 ￥850



134 27 086
オブロンググラタン
L-19.4 S-11.4 H-3.7 ￥1,800



134 27 056
片手スープカップ
L-14 S-11.8 H-6.6
C-350cc ￥1,500



134 27 054
両手スープカップ
L-16.8 S-11.8 H-6.6
C-350cc ￥1,600



134 27 062
高台スタックコーヒーカップ
L-10.9 S-8.3 H-6
C-185cc ￥1,100



134 27 052
コーヒーカップ
L-10.7 S-8.4 H-6.7
C-170cc ￥900



134 27 053
ティーカップ
L-11.8 S-9.5 H-6.1
C-225cc ￥900



161 27 055
モア兼用ソーサー¹
D-15.3 H-2.5 ￥650

161 27 055
モア兼用ソーサー¹
D-15.3 H-2.5 ￥650

134 27 062
高台スタックコーヒーカップ
L-10.9 S-8.3 H-6
C-185cc ￥1,100

134 27 055
兼用ソーサー¹
D-15.2 H-1.9 ￥600

134 27 055
兼用ソーサー¹
D-15.2 H-1.9 ￥600



134 27 050
マグカップ
L-11.3 S-8.8 H-9.2
C-315cc ￥1,000



134 27 060
シュガー
D-8.3 H-9.3
C-255cc ￥2,100



134 27 063
クリーマー
L-11.1 S-6.3 H-7.6
C-180cc ￥1,900



134 27 035
スタックスープボウル
D-10.3 H-6.3
C-260cc ￥900



134 27 098
7.5cmソースカップ
D-7.6 H-4.4
￥700



134 27 099
6cmソースカップ
D-6.2 H-3.6
￥600