



161 11 001
31cm大皿
D-31 H-3.7 **¥4,100**



161 11 002
27.5cmディナー皿
D-27.6 H-3.7 **¥1,900**



161 11 004
24cmミート皿
D-24 H-3.3 **¥1,300**



161 11 005
21.5cmデザート皿
D-21.5 H-3 **¥1,100**



161 11 006
19cmケーキ皿
D-19.2 H-3 **¥850**



161 11 007
17.5cmパン皿
D-17.5 H-2.5 **¥750**



161 11 008
15.5cmパン皿
D-15.7 H-2.4 **¥700**



161 11 042
32cmプラター
L-32 S-21.6 H-3 **¥4,400**



161 11 012
22cmカレースパゲティボウル
D-22.4 H-3.7 **¥1,300**



161 11 014
18.5cm浅ボウル
D-18.5 H-4.7 **¥1,100**



161 11 015
14cm浅ボウル
D-14.3 H-3.8 **¥750**



161 11 016
10cm浅ボウル
D-10.2 H-3 **¥700**



161 11 073
仕切り皿
L-13.7 S-8.4 H-2.2
¥1,100



161 11 050
アメリカンカップ
L-11.8 S-9 H-8.3 C-270cc **¥750**



161 11 052
コーヒーカップ
L-11 S-8.2 H-7.6 C-180cc **¥700**



161 11 054
片手スープカップ
L-14.4 S-11.8 H-6.7 C-350cc **¥1,300**



161 11 069
スティックシュガー
L-9.5 S-7 H-8.5 **¥1,400**

161 11 055
兼用ソーサー
D-15.3 H-2 **¥600**

161 11 055
兼用ソーサー
D-15.3 H-2 **¥600**

161 11 055
兼用ソーサー
D-15.3 H-2 **¥600**

材質：テラコッタ



103 05 102
ピッチャー **[CN]**
L-16.8 S-12.2 H-15.8 C-1,050cc
¥2,800



103 05 043
オイルボトル **[CN]**
D-7 H-13.5 C-210cc
¥950



103 05 064
手付パン **[CN]**
L-19.8 S-9.3 H-1.5 C-620cc
¥1,800



103 05 016
ディップディッシュ **[CN]**
D-8.1 H-2.4
¥650